For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec. #lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the **Single Cup** or **Double Cup** button.

Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press Boiler ~10s. On/Stby & Boiler lamps blinking. Each 2 Cup press, -1C. Each 1 Cup press, +1C. Press On/Off to exit.

For first three modes below: Start with VII On, **hold On/Off** button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press **On/Off** button to save and exit programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec. #lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the Single Cup or Double Cup button.

Press the same button again when proper volume achieved.

Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press *Boiler* ~10s. On/Stby & Boiler lamps blinking. Each 2 *Cup* press, -1C. Each 1 *Cup* press, +1C. Press *On/Off* to exit.

For first three modes below: Start with VII On, *hold On/Off* button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press *On/Off* button to save and exit programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec.
#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the Single Cup or Double Cup button.

Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press *Boiler* ~10s. On/Stby & Boiler lamps blinking. Each *2 Cup* press, -1C. Each *1 Cup* press, +1C. Press *On/Off* to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming

programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec.

#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the Single Cup or Double Cup button.

Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press *Boiler* ~10s. On/Stby & Boiler lamps blinking. Each 2 *Cup* press, -1C. Each 1 *Cup* press, +1C. Press *On/Off* to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec.

#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the Single Cup or Double Cup button.

Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press Boiler ~10s. On/Stby & Boiler lamps blinking. Each 2 Cup press, -1C. Each 1 Cup press, +1C. Press On/Off to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming.

button down for ~3sec.

lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

* Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the Single Cup or Double Cup button.

Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press Boiler ~10s. On/Stby & Boiler lamps blinking. Each 2 Cup press, -1C. Each 1 Cup press, +1C. Press On/Off to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming.

#lamps lit = secs preinfusion - Hold *Boiler* button down for ~3sec.
#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the *Single Cup* or *Double Cup* button. Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press *Boiler* ~10s. On/Stby & Boiler lamps blinking. Each 2 *Cup* press, -1C. Each 1 *Cup* press, +1C. Press *On/Off* to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec. #lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)

Fill PF with coffee. Press the *Single Cup* or *Double Cup* button. Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press **Boiler** ~10s. On/Stby & Boiler lamps blinking. Each **2** Cup press, -1C. Each **1** Cup press, +1C. Press On/Off to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming

programming.

Programmable Pre-infusion - Hold *Boiler* button down for ~3sec.

#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

Dose Setting (to program single or double cup button)
Fill PF with coffee. Press the Single Cup or Double Cup button.
Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press *Boiler* ~10s. On/Stby & Boiler lamps blinking. Each 2 *Cup* press, -1C. Each 1 *Cup* press, +1C. Press *On/Off* to exit.

For first three modes below: Start with VII On, hold On/Off button down til On/Stby & current Temp lamps start flashing (~3sec). Once instructions below completed, press On/Off button to save and exit programming.

programming.

Programmable Pre-infusion - Hold Boiler button down for ~3sec.

#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection.

#lamps lit = secs preinfusion (0-8s). Each Boiler press cycles selection **Dose Setting** (to program single or double cup button)

Fill PF with coffee Press the Single Cup or Double Cup button

Fill PF with coffee. Press the *Single Cup* or *Double Cup* button. Press the same button again when proper volume achieved.

Master Temp Setting

Current temp setting displayed. Press the *Hot Water* button to cycle to the next Temp.

Extended Offset Temp Setting

Start in Stby mode. Press *Boiler* ~10s. On/Stby & Boiler lamps blinking. Each 2 *Cup* press, -1C. Each 1 *Cup* press, +1C. Press *On/Off* to exit.